

# BOL LED BRACKET (BOLBRACKET)

Installation Instructions/Consignes d'installation/Montageanleitung



COLLINGWOOD  
LIGHTING

EN

---

## INSTALLATION

1. Mark out location holes for the base using the bracket as a template.
2. Drill fixing holes with 14mm masonry drill bit, minimum depth 55mm.
3. Insert expanding shields into drilled holes.
4. Position bracket over holes, insert fixing bolts and tighten down.
5. Place BOL LED in position and insert coach bolts.
6. Attach Ni-Lock nuts and tighten.

FR

---

## CONSIGNES D'INSTALLATION

1. Marquez les emplacements pour les trous sur la base en utilisant le support en inox comme référence.
2. Percez les trous avec une perceuse équipée d'un foret de 14mm, la profondeur minimale doit être de 55mm.
3. Insérez les chevilles à expansion dans les trous précédemment percés.
4. Positionnez les supports sur les trous, insérez les vis et serrez.
5. Placez la borne BOLLED en position et insérez les boulons carrossier.
6. Attachez les écrous frein et resserrez.

DE

---

## INSTALLATION

1. Markieren Sie Aufnahmebohrungen für die Basis unter Verwendung der Halterung als Schablone.
2. Bohren Sie Befestigungslöcher mit einer Mindestdtiefe von 55mm mit einem 14mm Steinbohrer.
3. Setzen Sie Spreizanker in die Bohrungen ein.
4. Positionieren Sie die Halterung über den Bohrungen, führen Sie Befestigungsschrauben ein, und ziehen Sie sie fest.
5. Bringen Sie die BOLLED in Position, und führen Sie Schlossschrauben ein.
6. Bringen Sie die Muttern an, und ziehen Sie sie fest.