

XtremeMats

THE ULTIMATE HEAVY DUTY ACCESS MATTING SYSTEM

Installing with four-leg chains

1. Attach two of the chain legs using special Mega-Thread bolts into the two threaded holes on one side (or end) of the mat.
2. The other two chain legs are equipped with self-expanding clamps which should be inserted through the opposite two holes. Pull the chain taught by hand, and ensure that the shackle pin has slid fully to the end of its slot which expands the clamp and locks it in that position whilst under load tension.
3. As the mat is lowered into position, insert the prodder bars through two free holes to guide the mat down accurately over the connector thread.
4. Insert Mega-Thread joining bolts, and tighten them fully using the T-bar.



Ground-Guards®

Tel: 0113 267 6000

Web: www.ground-guards.co.uk