


Fitting Instructions, Norsound 695

Tools Required



Length

Installation Detail

It is not necessary to remove the door (s) from hinges.

1: Measurement

Remove plate from packaging, measure the width of the door opening from stop to stop, mark thresh with a pencil the desired length for cutting.

2: Cutting to size

Using a saw cut to size then position thresh in place making sure that the carpet fits under the rear of thresh.

3: Screw fix

Using a drill with a 3mm drill bit, drill holes in thresh using the guide channel, screw holes should be approx 75mm in from both ends and 200mm apart. Making sure to countersink each individual fixing hole to ensure screws are flush when fitted. Screw fix using screws and plugs supplied.

Description of contents

1: Aluminium thresh

2: Screws and plugs

Other Norsound seals include

Perimeter seals

Door bottom seals

Automatic door bottom seals

Additional threshold plates

All designed for your acoustic needs

Important

Ensure that the installation of this Product does not impede the opening Or closing of door leaf or leaves.

Note

Recommendations as to methods for use of materials and construction details are based on the experience and knowledge of Norsound and are given in good faith as a general guide and service to designers, contractors and manufacturers.

Norsound reserves the right to make alterations or delete any installation detail without prior notice.

Drill bit guide channel

