

## Cleaning Guidelines: Stair Nosings

### Material Type – Aluminium carrier with PVC infill: S-Range, H-Range, Z-Range

- Clean aluminium carrier with a mild detergent solution then polish with a clean dry cloth.  
If required use a scouring pad to remove any ingrained dirt.
- Clean infill with a mild detergent solution using a scouring pad to remove any heavy soiling.
- Dry off if necessary with lint free cloth.

**Do not traffic whilst wet!**

### Material Type – Brass carrier with PVC infill: BF1, BR1, BB1, BCF2, BT trim

- Clean carefully with metal polish avoiding contact with infill as this may cause staining.  
Polish with clean dry cloth.
- Clean infill with a mild detergent solution using a scouring pad to remove any heavy soiling.
- Dry off if necessary with lint free cloth.

**Do not traffic whilst wet!**

### Material Type – PVC-u: SPF, SPR, SPB, HPF, HPR, HPB

- Both infill and nosing should be cleaned with a mild detergent solution.
- Dry off if necessary with lint free cloth.

**Do not traffic whilst wet!**

**DO NOT USE SOLVENTS !**

If you require any further details please e-mail  
[technical@quantum-ps.co.uk](mailto:technical@quantum-ps.co.uk)

Quantum Profile Systems Ltd / August 2014