

**RANGE**  
green ■ safe ■ clean

# Installation Guidelines

## Drill and Plug

Starting at the top of the stair case:

1. **Fit the floor covering to the tread and riser of the stair, if using contact adhesive we recommend that you leave approx 40-50mm un-coated at the front of each step.**
2. **Ensure that the step edge surfaces are clean, smooth and clear of debris.**
3. **Position the stair nosing on top of the floor covering ensuring that it is the correct size. Then using the back edge of the stair nosing as a guide, scribe the floor covering. Remove the waste floor covering material from the step.**
4. **Re-position the stair nosing and again, using the pre-drilled holes as a guide mark the position of each of the holes (If your nosing is not pre drilled please ask for a copy of our Q-Range drilling and packing guidelines).**
5. **Drill in the marked positions using the correct sized drill bit for the screws being used. Plug the hole with a standard plastic plug.**
6. **Apply an cartridge adhesive as per the manufacturers' instructions to the underside of the stair nosing.**
7. **Position the stair nosing on the step, press down and screw into position. Ensure that the screws are installed in as close to vertical as possible as this will aid the installation of the plugs. Note the nosing should be installed**
8. **Fill the drill holes using a Plug of the same colour as the tread material – these should be supplied with your stair nosings.**
9. **Move down to the next step and repeat the process.**

\* These fitting guidelines (and full instructions available from Quantum) have been prepared by the manufacturer using reasonable care and skill. Due to the variety of conditions and locations in which the stair nosings may be fitted, these are for guidance only. The manufacturer cannot accept any liability for defective fitting arising out of the acts, omissions, negligence or default of the fitter, its servants or agents, including in particular (but without prejudice to the generality of the foregoing) any failure by the fitter to comply with any recommendations of the manufacturer as to the fitting of the stair nosings, including these instructions.