



# SURESPAN

## Fitting IAC Internal Access Cover

1. Check size of structural opening and recessed dimensions against overall frame sizes to determine packing/grout requirements to ensure top of frame will be flush with F.F.L. if required.
2. Using slings if necessary lower access cover into structural opening.
3. Check gas spring bracket(s) are flush with inside of hole. Pack if necessary. It is critical that the gas spring brackets are vertical and solid against the inside of the opening.
4. Fit frame in position, drill suitable holes through the frame to get good fixings into the side of your structural opening using 6mm or 8mm fixings.
5. Check access cover by open and closing lid. Insert the 'Tee' key into the hole nearer the edge and turn to release lock before lifting.

For further information contact:

**Surespan Limited**

Leamore Close

Leamore Enterprise Park

Walsall

West Midlands

WS2 7NL

Tel: +44 (0)1922 711185

Fax: +44 (0)1922 714099

Email: [sales@surespancovers.com](mailto:sales@surespancovers.com)



# SURESPAN