



### **Flipfix 3 Minute Fitting Instructions**

#### **3 Minute Fitting**

- Cut out the hole using template provided and a pad saw
- You don't need to remove the door, just open the panel using the key supplied and place the panel into the aperture.
- Tighten the flip fix device via the fixing screw behind the door leaf to clamp onto the back of the plasterboard (the flipfix device covers all boards from 8mm – 32mm). You can alternatively screw through the frame using optional fixing points if screwing into existing timber surround.
- Lock the door and insert the plastic bung cover into the lock hole.

Now sit back and relax, you have saved yourself 20 minutes