

PROFESSIONAL SOUNDBLOC

Description:

- High quality PE foam underlay.
- Reduces impact sound and Reflected Walking Sound to the bare minimum.
- Suitable for installation under laminate and parquet click floors.
- Easy to install



Characteristics:

Properties	Typical result	Test Method
Product code	PGUDLPS15 / PGUDLPS50	
Colour	Gray / Anthracite	
Material	Polyetheen	
Shape	Rolls of 15 or 50m ²	
Thickness	2mm	EN 823
length	15789 / 52632 mm	EN 822
width	950mm	EN 822
Compression strength (At 0.5mm deformation)	140kPa (14,3 ton/m ²)	EN 826
Fire protection classification	E _{fl}	EN 13501-1
Thermal conduction resistance	0.053 m ² °K/W	DIN 4108
Deflection temp. under load	<70° C	
Impact sound insulation	ΔL _w = 20dB	ISO 140-8
Walking noise reduction	-30%	IHD 431
Sd-Value	> 75m	DIN 52615

Installation instructions:

1. Lay the underlay in rows with the Damp Proof Membrane (side without embossed Pergo® logo) on the top side, parallel to the laying direction of your Pergo® floor.
2. In the first row, put the Damp Proof Membrane flap up against the wall. Afterwards you can cut off the DPM so there is only 2 cm left.
3. Install the following row next to the first. Remove the adhesive strip and fold back the DPM flap of the second row.
4. Make sure the underlay fits together tightly (don't leave any gaps) and the DPM is attached perfectly. against the wall.
5. To join rolls on the short side, always use a damp proof tape.

