



- When cleaning the stainless steel paper towel dispenser and bin, check for dirt and grease and wipe clean as directed in the 'Care of finishes' section.
- To open the panel, insert the Modric key supplied into the concealed lock (fig.1).

## weekly checks

- If the panel door has dropped and you need to realign the panel door position, turn the screw (fig. 2) to the desired position until the door sits flush into the panel.
- If the panel door has become tight and difficult to open/close adjust the ball catch accordingly (fig.3).
- If panel door has become loose tighten screw on hinge (fig.4).

## monthly checks



The Modric washroom panels were designed with the end user in mind, making refilling and cleaning easy.

- **When refilling the papertowel dispenser, fill from the top (fig.5).**
- **Remove dust, fluff and any other build up of foreign matter from the inlet and outlet grille areas (Fig.6).**
- **When emptying the bin, remove the bin receptacle by lifting from the panel casing and dispose as necessary.**

weekly checks



### Satin Stainless Steel

Wipe clean with a medium strength detergent or white spirit using a soft cloth or sponge. Rinse and dry with a dry soft cloth. In the event of dirt having accumulated through neglect, application of aerosol lubricant prior to standard cleaning is recommended. A harsh brush should never be used.

**Finish prefixes: SS**

### Polished Stainless Steel

Wipe clean with a medium strength detergent or white spirit using a soft cloth or sponge. Rinse and dry with a dry soft cloth. In the event of dirt having accumulated through neglect, application of aerosol lubricant prior to standard cleaning is recommended. A harsh brush should never be used.

**Finish prefixes: PS**