

## Elementary Cleaning Procedure

### Shower Channels

- Remove the grate
- Clean the channel recess using a soft cloth & warm soapy water
  
- When a removable siphon is fitted (such as those using the Multi trap system), you can also :
  - remove the components and clean them using soft cloth & warm soapy water
  - while removed, you also have open access to the trap body, & the connecting pipework, for cleaning
- Replace components in the reverse order to how they were removed
  
- Also refer to the Care & Maintenance Instructions for Stainless Steel