








Outlet/inlet extension AR35XTT10/15/20






AR35XTT - Inlet part 1




AR35XTT - Inlet part 2





AR35XTT - Outlet part 1

17



18



AR35XTT - Outlet part 2

19



20



130-210 mm



Main office

Frico AB
 Box 102
 SE-433 22 Partille
 Sweden

Tel: +46 31 336 86 00
 Fax: +46 31 26 28 25
 mailbox@frico.se
 www.frico.se

**For latest updated information and information
 about your local contact: www.frico.se**