

To Operate

Switch Power On or Press Re-Set
Buzzer will Bleep

Fill



- 1 Place Hose **B** in sample container
- 2 Press Fill Button and release
- 3 At required level press Fill button again

Re-Set



Unit is now set for repeat filling of the same amount
Position fill hose in next container and press Fill button
Buzzer will sound on completion

To Change Fill amount

Press Re-Set and continue from stage 1

Outlet
B



Hoyles Electronic Developments Ltd

T. 01744 886600 F. 01744 886607 E. sales@hoyles.com W. www.hoyles.com

Inlet
A