



- **When cleaning the stainless steel soap dispenser** check for dirt and grease and wipe clean as directed in the 'Care of finishes' section.
- **To refill the soap dispenser,** remove the sleeve by insurting the Modric key supplied (Fig.19) turning anti-clockwise and lifting the sleeve off (Fig.20). Remove the plastic cap (Fig.21) and pour the liquid soap into the dispenser.

### weekly checks

- **If the dispenser has become loose,** check that the fixings are tight and that there is no movement on the cap bracket or fixings to the wall. If the items are loose, please tighten the relevant fixings (Fig.16).

### monthly checks



#### Satin Stainless Steel

Wipe clean with a medium strength detergent or white spirit using a soft cloth or sponge. Rinse and dry with a dry soft cloth. In the event of dirt having accumulated through neglect, application of aerosol lubricant prior to standard cleaning is recommended. A harsh brush should never be used.

**Finish prefixes:** SS

#### Polished Stainless Steel

Wipe clean with a medium strength detergent or white spirit using a soft cloth or sponge. Rinse and dry with a dry soft cloth. In the event of dirt having accumulated through neglect, application of aerosol lubricant prior to standard cleaning is recommended. A harsh brush should never be used.

**Finish prefixes:** PS