

BC 5083-01 – BC 5083-05 Dolphin Stainless Steel Support Rails

User Manual

Please read carefully before use



GRAB BAR

BC5083-01 BC5083-02 BC5083-03 BC5083-04 BC5083-05

SPECIFICATIONS:

Material – 304 Stainless Steel, 1-1/4" O.D. tubing

Includes – Mounting Hardware

INSTALLATION:

1. Grab bars are to be mounted to a secure surface.
2. Please note all screws must mount firmly into a wood stud.
3. Place the grab bar on the wall where desired so that the mounting holes are positioned over a wood stud.
4. With a pencil, mark the mounting holes' locations.
5. Remove product from the wall and drill holes at the marked locations.
6. Mount the grab bar with screw set provided.
7. If mounting a Concealed screw grab bar, press the cover plate over the grab bar screw base.





Bell-Chem Products Company
Haywood Way, Hastings, TN35 4PL
Tel: 01424 202224
info@dolphindispensers.co.uk
www/dolphindispensers.co.uk