

Wash hand basin

Electrically powered height adjustable – **vertical** movement only

Electrical requirements

1. 3 amp unswitched spur at ceiling height above wash hand basin position.
This supply used to connect to transformer via wall trunking.

Waste requirements

2. 32mm waste located 200mm either side of a centre line through basin frame.
3. Waste needs to be 260mm from the floor.

Water feeds

4. Hot and cold feeds via ½" flexible hoses.
5. Connection: one either side, 200mm of a centre line through the basin frame.
6. Feeds need to be 340mm from the floor.

