




RAND 111◇
*** 73 00◇
*** = JAC / M10
◇ = A / B / W
G53 / 12V / EXCL. TRANSFO


 1 X QR-LP111 35-50-75-100W

ACCESSORIES
CLIP 111 + FRONTGLASS 111
CLIP 111 + COLOUR FILTER 111
CLIP 111 + LENS 111



ACCESSORIES / OPTIONS:

CLIP 111 A
201 27 99 A



22
Ø110

FRONTGLASS 111
201 17 00



Ø100

COLOUR FILTER 111
201 27 11 (BLUE)
201 27 12 (GREEN)
201 27 13 (RED)
201 27 14 (YELLOW)




Ø100

LENS 111
201 47 11



Ø100

CONE 111
201 28 00 ALU
201 28 00 B
201 28 00 C
201 28 00 W



26
Ø80
Ø117
MAX 50W
MAX.24
SS

WAARSCHUWING
AVERTISSEMENT
WARNUNG
WARNING
AMMONIZIONE
EDVERTENCIA

Lees de algemene gebruiksvoorwaarden : **DEEL B**
Lire attentivement les conditions générales d'utilisation : **PARTIE B**
Lesen Sie die allgemeinen Gebrauchsanweisungen : **TEIL B**
Read the general directions : **PART B**
Leggere attentamente le condizioni generali di utilizzazione : **PARTE B**
Leer atentamente las condiciones generales de uso : **PARTE B**





Verlichtingstoestellen die ontworpen zijn om alleen gebruikt te worden met zelfbeschermende halogeen wolframlampen
Luminaires conçus pour être utilisés uniquement avec des lampes tungstène halogène autoprotégées
Lampen, die nur zur Verwendung mit Tungsten-Halogenlampen konzipiert und
Luminaires designed for use with self-shielded tungsten halogen lamps only
Luminarias diseñadas para ser utilizadas únicamente con lámparas de tungsteno halógeno autoprotegidas
Apparecchi di illuminazione per l'uso unicamente con lampade al tungsteno alogene



Enkel geschikt voor toestellen op zeer lage spanning (minder dan 50 V AC)
Convient uniquement pour les produits à très basse tension (moins de 50 V AC)
Geeignet für Güter mit sehr niedriger Spannung (unter 50 V AC)
Only suited for goods at very low voltage (below 50 V AC)
Se recomienda únicamente para aquellos productos de tensión muy baja (menos de 50 V AC)
Vale unicamente per i prodotti a tensione molto bassa (inferiore a 50 V AC)



Installeer het armatuur enkel in ruimten waar direct contact met water onmogelijk is.
Cet équipement doit être installé dans des pièces hors de toute projection d'eau.
Diese Leuchte darf nur in Räumen verwendet werden, in denen ein direkter kontakt mit wasser nicht möglich ist
This fitting should only be installed in rooms where direct contact with water is impossible
Este aparato solamente puede ser instalado en habitaciones donde el contacto directo con el agua sea imposible
Questo apparecchio di illuminazione deve essere installato solamente in locali in cui il contatto con l'acqua è impossibile.



Opgepast warm oppervlak - niet aanraken - buiten bereik installeren
Attention surface de contact chaude - ne pas toucher - installer hors d'atteinte
Achtung heisse Oberfläche - Nicht Berühren - Nur unerreichbar installieren
Caution hot surface - do not touch - install out of reach
Precaucion alta temperatura de la superficie - no tocar - instalar fuera de alcance
Attenzione superficie calda - non toccare - installare in luogo non accessibile




Minimum afstand van de verlichte voorwerpen (meter)
Distance minimale par rapport aux objets éclairés (mètres)
Mindestabstand von beleuchteten Gegenständen (Meter)
Minimum distance from lighted objects (metres)
Distancia mínima de los objetos iluminados (metros)
Distanza min. dagli oggetti illuminati (metri)




Bevestiging wand - plafond opbouw
Montage mur - plafond appliqué
Montage wand - decke aufgebaut
Fixation wall - ceiling surface mounted
Montaje pared - techo montado al superficie
Montaggio parete - soffitto montato a superficie

INSTALLATION INSTRUCTIONS - PART A


- 01. INSERT / REPLACE LAMP
- 02. MAKE ELECTRICAL LAMP-CONNECTION
- 03. INSERT DEVICE WITH INSTALLED OPTION FOR JACK, DELTA CLIP, DAX CLIP OR M10
- 04. SWITCH ON



JAC
OPTION EXAMPLE
JACKPOINT
203 10 01 A/B/W




02






03



M10
OPTION EXAMPLE
M10
M10 73 00 A



03



CLIP 111 A
201 27 99 A

BY USING CLIP 111 A, REMOVE THE SPRING
(INSTRUCTION 01b)