




**Standard installation**

Closer mounted on door on pull side




**CLOSING POWER ADJUSTMENT**





**Right hand door shown**  
Same dimensions apply for left hand door measured from hinge edge

**POSITION OF ARMS AND INDEX SETTINGS**




**Top jamb installation**

Closer mounted on top jamb on push side of door.  
Reveals of 70 to 127 requires long top jamb forearms




**CLOSING POWER ADJUSTMENT**



**Left hand door shown**  
Same dimensions apply for right hand door measured from hinge edge

**POSITION OF ARMS AND INDEX SETTINGS**



**THE PARKSIDE GROUP LTD**

UNIT 5, THE WILLOW CENTRE  
17 WILLOW LANE, MITCHAM, SURREY, CR4 4NX  
Tel: 020-8685 9685 Fax: 020-8646 5096  
Email: axim@parksidegrp.co.uk  
Web Site: http://www.axim.co.uk

SCALE NTS @A4

DATE MARCH 2014



For scaled technical or CAD drawings,  
please contact AXIM.

**Parallel arm installation**



Closer mounted on door on push side

**Left hand door shown**

Same dimensions apply for right hand door measured from hinge edge.



**POSITION OF ARMS AND INDEX SETTINGS**



**Instructions**

Step 1

- A. Check hand of door.
- B. Select type of installation.

Step 2

- A. See instructions for installation you have selected.
- B. Follow instructions for correct application and adjustment.

Step 3

- A. Apply closer body and forearm (or parallel bracket and forearm) to door and frame as shown.
- B. Place main arm on shaft at proper index mark as shown and tighten arm screw with lockwasher securely.
- C. Adjust length of forearm as shown and attach to main arm at elbow and tighten locknut bolt.


Step 4

Fixing cover cap on shaft at unused side and insert rubber plug into one of unused fixing hole on body then slide in the Faceplate.

Step 5

Door closing and latching speeds are controlled by #1, #2 speed regulating screw separately.


- A. Clockwise turns slow the Speed.
- B. Counterclockwise turns increase the speed.




**THE PARKSIDE GROUP LTD**

UNIT 5, THE WILLOW CENTRE  
17 WILLOW LANE, MITCHAM, SURREY, CR4 4NX  
Tel: 020-8685 9685 Fax: 020-8646 5096  
Email: axim@parksidegrp.co.uk  
Web Site: <http://www.axim.co.uk>

SCALE	NTS @A4
DATE	MARCH 2014
For scaled technical or CAD drawings, please contact AXIM.	







**THE PARKSIDE GROUP LTD**

UNIT 5, THE WILLOW CENTRE  
17 WILLOW LANE, MITCHAM, SURREY, CR4 4NX  
Tel: 020-8685 9685 Fax: 020-8646 5096  
Email: axim@parksidegrp.co.uk  
Web Site: <http://www.axim.co.uk>

SCALE	NTS @A4
DATE	MARCH 2014
For scaled technical or CAD drawings, please contact AXIM.	






**THE PARKSIDE GROUP LTD**

UNIT 5, THE WILLOW CENTRE  
17 WILLOW LANE, MITCHAM, SURREY, CR4 4NX  
Tel: 020-8685 9685 Fax: 020-8646 5096  
Email: axim@parksidegrp.co.uk  
Web Site: <http://www.axim.co.uk>

SCALE	NTS @A4
DATE	MARCH 2014
For scaled technical or CAD drawings, please contact AXIM.	



**THE PARKSIDE GROUP LTD**

UNIT 5, THE WILLOW CENTRE  
17 WILLOW LANE, MITCHAM, SURREY, CR4 4NX  
Tel: 020-8685 9685 Fax: 020-8646 5096  
Email: axim@parksidegrp.co.uk  
Web Site: <http://www.axim.co.uk>



SCALE NTS @A4

DATE MARCH 2014

For scaled technical or CAD drawings,  
please contact AXIM.

**Parallel arm installation**


Closer mounted on door on push side




for openings to 105° - 220 (8<sup>21</sup>/<sub>32</sub>)  
for openings to 180° - 150 (5<sup>29</sup>/<sub>32</sub>)

for openings to 105° - 230 (9<sup>1</sup>/<sub>16</sub>)  
for openings to 180° - 160 (6<sup>19</sup>/<sub>64</sub>)


LEFT HAND DOOR shown.  
Same dimensions apply for right hand door  
measured from hinge edge.



**POSITION OF ARMS AND INDEX SETTINGS**



**CHART FOR HAND OF DOOR**



**Instructions**

**Step 1**

- A. Check hand of door.
- B. Select type of installation.

**Step 2**

- A. See instructions for installation you have selected.
- B. Follow instructions for correct application and adjustment.

**Step 3**


- A. Apply closer body and forearm (or parallel bracket and forearm) to door and frame as shown.
- B. Place main arm on shaft at proper index mark as shown and tighten arm screw with lockwasher securely.
- C. Adjust length of forearm as shown and attach to main arm at elbow and tighten locknut.

**Step 4**

- Snap cover cap over shaft at unused side.

**Step 5**

- Door closing and latching speeds are controlled by #1, #2 speed.
- Regulating screw separately.
- A. Clockwise turns slow the speed.
- B. Counterclockwise turns increase the speed.





**THE PARKSIDE GROUP LTD**

UNIT 5, THE WILLOW CENTRE  
17 WILLOW LANE, MITCHAM, SURREY, CR4 4NX  
Tel: 020-8685 9685 Fax: 020-8646 5096  
Email: axim@parksidegrp.co.uk  
Web Site: <http://www.axim.co.uk>


SCALE	NTS @A4
DATE	MARCH 2014
For scaled technical or CAD drawings, please contact AXIM.	

**Standard installation**

Closer mounted on door pull side




**CLOSING POWER ADJUSTMENT**



Arrow toward hinge edge  
- for regular power

Arrow away from hinge edge  
- for maximum power

**POSITION OF ARMS AND INDEX SETTINGS**





**Right hand door shown**

Same dimensions apply for left hand door measured from hinge edge.


**Top jamb installation**

Closer mounted on top jamb on push side of door.

Reveals of 70 (2 3/4") to 127 (5") requires long top jamb forearms.




**CLOSING POWER ADJUSTMENT**



Arrow toward hinge edge  
- for regular power

Arrow away from hinge edge  
- for maximum power

**POSITION OF ARMS AND INDEX SETTINGS**



**Left hand door shown**

Same dimensions apply for right hand door measured from hinge edge.



**THE PARKSIDE GROUP LTD**

UNIT 5, THE WILLOW CENTRE  
17 WILLOW LANE, MITCHAM, SURREY, CR4 4NX  
Tel: 020-8685 9685 Fax: 020-8646 5096  
Email: axim@parksidgrp.co.uk  
Web Site: http://www.axim.co.uk

SCALE NTS @A4

DATE MARCH 2014

For scaled technical or CAD drawings,  
please contact AXIM.