

# DURABELLA Flooring Solutions

Specialists in Acoustic, Access and Leisure Flooring Systems



## Data Sheet

01274 533311 . info@durabella.co.uk

Low Level

Ceramic/Stone Tiles . Thermal . Acoustic/Impact

## DuraCork T93


### Top Performance Impact Noise Reduction Underlay

Top Impact Noise and Thermal Insulation in One Product

Installed Directly Under the Final Floor

Enhances Walking Comfort

High Durability and Long Term Resilience



#### PRODUCT DESCRIPTION

Two Laminated Layers (Agglomerated Cork & Recycled Rubber) for Top Impact Noise and Thermal Insulation of Ceramic Tiles and Stone.

#### PACKAGING

915mm x 610mm x 9.5mm

\*Other sizes available upon request

#### ACOUSTICAL RESULTS

(ISO 140 & 717)

$\Delta L_w = 20\text{dB}$

(SRL C/07/5L/20096/R02)

#### THERMAL PROPERTIES

(ISO 8301)

Thermal Conductivity:  $0.070 \text{ W/m}^2\text{K}$

Thermal Resistance:  $0.136 \text{ m}^2\text{K/W}$

#### PHYSICAL AND MECHANICAL PROPERTIES

(ISO 7322)

Specific weight:  $370\text{--}450 \text{ Kg/m}^3$

Tensile Strength:  $>600 \text{ KPa}$

Compression: 15%

Recovery  $>90\%$

Durability: Lifetime of the Building

#### GENERAL INSTALLATION INSTRUCTIONS

The following installation instructions are recommended by Durabella Acoustics Limited, but are not intended as a definitive project specification. They are presented in an attempt to be used with recommended installation procedures of the flooring manufacturers.

#### Room Conditions

Temperature  $>10^\circ\text{C}$  / Room moisture content  $< 75\%$

#### Subfloor

All subfloor work should be structurally sound, clear and level. The moisture content of the subfloor should not be more than 2.5% (CM) by weight measured on concrete subfloors.

#### Perimeter Insulation Barrier

Install a perimeter insulation barrier minimum 35mm wide vertically around the entire perimeter of the room. This is highly recommended in order to avoid lateral propagation of impact noise. Spot adhere the strips to the wall using acrylic glue or a bead of silicone sealant (do not forget the edges of pipes, ducts, etc). Before the installation of the skirting boards, the insulation strips must be levelled (trimmed) to the height of the tiles.

#### Installation Instructions for DuraCork T93

Unpack the DuraCork T93 at least 24h before the installation and store it in the room where the installation will take place. A properly sized V-notched trowel and polyurethane flooring adhesive should be used to glue the AcoustiCORK T93 to the concrete slab. Always follow the glue manufacturers recommended instructions.

Lay the DuraCork T93 sheets, with the rubber/cork side facing down into the bed of adhesive applied. Butt the sheets tightly against the perimeter insulation barrier already installed. Proceed to cover the entire floor making sure the joints are butted tight, without gaps and securely taped. Roll with a roller the floor area in both directions to make sure the sheets are firmly embedded in the adhesive.

#### Final Flooring

Use polyurethane based adhesive. Always follow manufacturers recommended installation instructions.

