

Technical Datasheet - Stair Nosing

GenStep Tread

Product Description

Gen Step is a unique rubber composite material that is anti slip, easy to clean, and extremely hard wearing.

Installed either internally or externally, GenStep can be used in conjunction with a wide range of materials including terrazzo, concrete, marble, stone and wood.


Dimensions and Colour

Stock lengths are 1.7m available in Black, WhiteGrey, Yellow and Brown.

GenStep can be cut and drilled to your specification upon request.

Produced in any width from 12mm - 295mm and available in 6mm or 8mm depth options.

Range



Maintenance

Preventative Maintenance

Regular maintenance prevents build up of dirt and grease which will reduce the anti slip properties of these inserts and lessen the visual impact.

Daily Cleaning

Sweep the area daily and spot clean any obvious marks or grease spots with a mild detergent and warm water. Very stubborn stains can be removed by gently using fine wire wool. Dry thoroughly after.

Weekly Cleaning

Sweep the area then clean the entire area with mild detergent and warm water. A green maintenance pad may be used. Change the water during this process to eliminate the spread of grime. After this process is complete the entire area should be thoroughly dried with a clean cloth.

NB Do not use polish or floor sealers on the GenStep inserts as this will adversely affect the slip resistance properties.

Installation

1. The surface or groove, to which GenStep will be applied, should be clean, dry and free from dust and loose particles. The specification for GenStep should be 1.0mm less than the width of the groove, and should project 0.5mm - 1.0mm proud of the surrounding surface. GenStep may be supplied predrilled for screw fixing with adhesive or undrilled for adhesive fixing only.
2. The predrilled GenStep insert should be offered up without adhesive applied onto the prepared surface and the holes marked out. Remove the GenStep insert and drill the prepared surface using a No. 6 drill bit. When drilling into concrete, a red plug should be used. Remove all dust and loose particles.
3. Apply the selected adhesive to the prepared surface. Follow the instructions on the adhesive container.
4. Place the GenStep insert into the adhesive and apply pressure to allow full adhesive transfer and to remove any air pockets.
5. Using No. 6 screws fix the GenStep insert into the adhesive and use the caps provided to cover the screw head.

NB Always allow sufficient time for the adhesive to fully cure before allowing foot traffic.

P.V.C. Trim • Stair Nosings • Expansion Joints • Transitions • Seals • Edge Protection • Metal Trim • Skirting • Tools

Tel: +44 (0)1642 713000

Email: info@genesis-gs.com

www.genesis-gs.com

UK Head Office & Factory
Stokesley Business Park Stokesley
North Yorkshire TS9 5JZ UK



Genesis
For the Perfect Finish

