

IMPORTANT INFORMATION

Opulus Pendant PN998/PN999



1. **NB:** Ensure electrical supply is isolated before fitting and/or making any electrical connections. Luminaires should be disconnected from the mains supply before any High Voltage Insulation tests are carried out.
2. Mark the fixing holes (50mm centres) and cable hole on the mounting surface.
3. Make provision for fixing the luminaire to the mounting surface.
NB: Ensure correct fixing method is used for both the mounting surface type and the weight of the luminaire.
4. Feed the mains/dimming cable through the hole in the mounting surface.
5. Make the mains and if applicable dimming connections to the connector block supplied in the ceiling plate according to the information on the luminaire mains/dimming cable.
6. Cut the luminaire mains/dimming to the required length allowing for small amount of cable in the surface plate.
7. Support the head of the luminaire and feed the luminaire cable through hole in front face of surface plate.
8. Make the mains and if applicable dimming connections to the connector block supplied in the ceiling plate according to the information on the cable..
9. Fix the ceiling plate to the mounting surface.
10. Loosen the knurled head of the suspension clutch (on the top of the luminaire) slightly but do not completely remove.
11. Pass the suspension wire through the suspension clutch by pushing down on the knurled head. The clutch will re-engage when knurled head is released which will support the luminaire temporarily.
12. Set the luminaire to the required height.
13. Re-tighten the knurled head of the suspension clutch.
14. Any surplus suspension wire can be cut away.
15. **NB:** For emergency versions remove centre disk by pushing to one side and easing down and make battery bullet connection, replace the centre disk. This operation must only be carried when a permanent mains supply is established.
16. Unscrew and remove the three nylon glass retaining screws whilst supporting the glass.
17. Fit the lamp into the lampholder in accordance with the lamp manufacturer's instructions and ensuring it is correctly located into the lampholder.
18. Re-fit the glass ensuring it is correctly fixed and located.
19. Reconnect the electrical supply and test the installation.

Hacel[®]
Fluent in Lighting

THE SILVERLINK, WALLSEND, NEWCASTLE UPON TYNE, TYNE & WEAR, NE28 9ND

TECHNICAL: (0191) 280 9914 E-MAIL: technical@hacel.co.uk WEB: www.hacel.co.uk

10/2015 79_0172